

# BEVCO®

## INSTRUCTION GUIDE FOR BEVCO SERIES 3000 REPAIR/MAINTENANCE STOOLS



### TO ASSEMBLE YOUR STOOL:

Place larger black end of cylinder into center hole in base tray. Place seat with control unit onto smaller end of cylinder. Carefully sit on seat with full weight to ensure tight fit on cylinder.

### TO ADJUST YOUR STOOL:

To raise the seat, lift your weight off the stool and pull upon the paddle lever located under the seat. Release the lever when the seat is at the desired height. To lower the seat, pull up on the lever while you are seated. Release the lever when the seat is at the desired height.

To lock the casters, push down on the caster brake lever with your foot. To unlock the casters, pull up on the caster brake lever with your foot.