

## CHANGING CYLINDERS

1. Remove back from chair
2. Turn chair upside down, holding onto cylinder, lift chair up off of floor
3. Using a rubber mallet, pound around seat of chair to remove seat from cylinder.  
Seat is on with a pressure fit so will come apart from cylinder  
It will take several hard hits around the seat to get it loose from cylinder  
It is okay to use a little WD40 if necessary
4. Remove footring by loosening handwheel and lifting it up and off of cylinder
5. Place base upside down on table or workbench with cylinder hanging over the edge of the table/workbench.
6. CAREFULLY pound around the edges of the cylinder bottom. DO NOT pound on the center part of the cylinder bottom.
7. Again, WD40 will help if you have a problem getting the cylinder out of the base.
8. Turn base over and place new cylinder in base
9. Place footring over cylinder and tighten handwheel
10. Replace seat on cylinder and press into place.
11. Replace back on chair.